

DIRECTIONS

For most surfaces and job conditions AC-3 should be diluted with 1 to 10 parts of water. Always use the mildest solution that can do the job. Tough stains and hardened mortar may require full strength.

First dampen surface with water. Apply AC-3 at proper strength to surface and agitate or scrub with nylon or other acid resistant brush for 2 or 3 minutes or until bubbling action stops. Rinse with clean water, agitate while rinsing. Do not do too large an area at one time, so that the loosened dirt may be allowed to settle back or dry. Repeat cleaning operation on stubborn stains as required.

Allow all surfaces to dry before waxing, painting or sealing. Terrazzo must be waxed or sealed as soon as dry.

When cleaning walls start at the bottom and work upward.

One gallon cleans approximately 300 sq. ft., depending on porosity and job conditions.

Guarantee All Florok Products are of the highest quality and guaranteed free of defects. Due to the broad range of job conditions and methods of application, test panel should be made to determine suitability of this product for job requirements. No responsibility can be accepted beyond purchase price.